

# EE2029: Introduction to Electrical Energy System What is the Real Power of a Generator?

Lecturer: Dr. Sangit Sasidhar

Department of Electrical and Computer Engineering

## **Learning Outcomes**

- Real Power Output
- Maximum Power Transfer
- Control of Real Power Output

## Real Power Output

• From

$$P_{3\Phi} = 3 \frac{|V||E|}{X} \sin(\delta)$$

- |V| and X are constant values.
- |E| depends on the magnitude of magnetic field at the rotor.
- When the magnetic field is kept constant and mechanical power input is increased, the electrical power output will be increased.
- Since |V|, |E|, and X are kept constant, power angle will be increased.

### Power Angle

• From

$$P_{3\Phi} = 3 \frac{|V||E|}{X} \sin(\delta)$$

Consider three cases:

Power angle	Real power output	Operation mode
δ > 0	P > 0	Supply power as generator
$\delta = 0$	P = 0	No power exchange
δ < 0	P < 0	Absorb power as a motor

This is why  $\delta$  is called 'power angle'!

#### Maximum Power Transfer

- In theory, the power angle  $\delta \leq 90$  degree.
- This limitation is called "Steady-state stability limit".
- Above 90 degree, generator will lose synchronism.

• The maximum power transfer is the real power output when the power angle

is 90 degrees.

electrical power output

increases


Under this region, when the mechanical power input increases, the power angle increase and as a result the

90 degree

 $P_{3\Phi} = 3 \frac{|V||E|}{V} \sin(\delta)$ 


Under this region, when the mechanical power input increases, the power angle increase BUT the electrical power output decreases. In order to balance mechanical power input to electrical power output, the machine will adjust its rotational speed, hence out of synchronism.

## Real Power Output



- Mechanical power input is increased by increasing the torque (τ). This results in a larger power angle and higher electrical power output.
- Steady-state stability limit is reached when power angle becomes 90 degrees.

## Control of Real Power Output



- |E|, |V| remains unchanged.
- Power angle increases as a result of higher mechanical power input.
- Load current |I| increases because the electrical power output is increased.
- The power factor will now change because the power angle is increased while the internal voltage magnitude is kept constant.
- We need to adjust the excitation voltage to keep the power factor constant.

## Control of Real Power Output

## Summary